

3

STEPS TO A LONG LASTING PAVER INSTALLATION....

Create a beautiful, long lasting paving installation using quality sand products from PACKAGE PAVEMENT®. Make sure you follow all instructions per the block manufacture for optimum results. These steps include creating a proper soil subgrade and sub-base for your pavers.

1 USE PATIO PAVER SAND FOR A STRONG BASE MATERIAL



QUIKRETE® PATIO PAVER - BASE SAND (Stone Dust) is the ideal base for your path or driveway. It provides the proper base for drainage and is a compactible product for use on top of your Item 4 base material.

2 CREATE A BEDDING BASE FOR THE PAVERS



QUIKRETE® ALL-PURPOSE SAND is an excellent base (bedding) for the pavers. Will provide a stable bed, and allow for drainage from the surface of your paving stones.

3 STABILIZE THE PAVERS USING JOINT-LOCK™ FINISHING SAND



FOR THE ULTIMATE IN A MAINTENANCE FREE INSTALLATION USE: JOINT-LOCK™ SAND.

JOINT-LOCK™ SAND is a polymer modified finishing sand designed to create a strong but flexible bond in the joints between pavers. Unlike ordinary jointing sand, JOINT-LOCK™ SAND remains in place and is designed to create a long lasting trouble free paver installation.

JOINT-LOCK™ SAND

